

Intu® Roller Blinds

Deep Bead Fitting Instructions



Made to Measure Window Blinds

Intu® Roller Blinds

Deep Bead Fitting Instructions

This Intu™ Roller Deep Bead blind was custom built to your exact requirements. High Quality materials and a design that is perfect in function and elegance guarantee a lifetime of long service.

Please read the following instructions carefully before installing your blinds

Intu[®] Roller Blinds

Deep Bead Fitting Instructions



1. Using fitting tool, insert top corner fixing bracket behind rubber bead, repeat on opposite side. N.B. Bracket positions must be manually adjusted when fitting side extrusions and headrail fascia based on frame shape and size.



2. Insert bottom corner fixing bracket behind rubber bead, repeat on opposite side.



3. Locate the profile bottom endcap over the bottom bracket, once fitted use side profile to position bottom fixing bracket.



4. Apply pressure to click home the profile top endcap.



5. Insert one side of fabric and corresponding bottom bar endcap into side profile and push headrail onto top corner brackets on both sides. N.B. Do not push blind fully home onto brackets.



6. On opposite side, tilt bottom bar to open position and slide profile over bottom bar endcap and fabric ensuring both are located within the fabric channel on the side profile.

Intu® Roller Blinds

Deep Bead Fitting Instructions



7. When the side profile is pushed all the way up and is in position, engage the side profile bottom bracket into the bottom corner fixing bracket.



8. Side profile can then be clipped home onto the top corner fixing bracket.
N.B. The position of the side profile can be adjusted up or down to help with fabric run off due to uneven window frames.



9. Position relevant number of side profile clips according to the drop of the blind. Push clips fully home.



10. Headrail fascia should be pushed fully on ensuring locks are engaged on both sides.

Intu[®] Roller Blinds

Deep Bead Fitting Instructions

