

ALUGLYDE/SOLOGLYDE BRACKET ADJUSTMENT

If the lever is difficult to turn to the lock position (horizontal position as shown fig.1):

Using rough sandpaper or a file, sand down slightly the 4 upstands on the bracket as shown by the black arrows in fig.2.

Continue until the lever is able to lock horizontally in the bracket.

