

INSTRUCTIONS FOR CHANGING THE TOOLS IN VARIO PLIERS

The Vario pliers are supplied with a set of tools to pierce a hole in the material and a set to close an eyelet.

Please note that the two closing tools are taped together when received.

TO INSERT THE HOLE CUTTING TOOL

The hole cutting tools consists of male and female components.

The pliers have a blue plastic insert in each of the holes that the tools are inserted into. These inserts grip the stem of the tool.

Insert one of the components into the blue insert. It is not important which component is fitted first.



The tool when inserted.



Push the other half of the cutting tool into the blue insert.



Pliers with cutting tool complete.



TO USE THE HOLE CUTTING TOOL

To cut the holes in the material place the material between the jaws of the pliers and squeeze.

TO REMOVE THE EYELET CUTTING TOOL

Push each component out from the back of the pliers.

TO INSERT THE EYELET CLOSING TOOL

Remove the tape from the tool to reveal the male and female components



It is not important which component is fitted first.

Push each part of the tool into the blue inserts as shown below.



TO CLOSE THE EYELET

Place the eyelet on the female component with the head of the eyelet down.



Place the hole in the material over the eyelet barrel.



Squeeze the pliers to close the eyelet.



TP REMOVE THE EYELET CLOSING TOOL

These are removed by pushing the stem of each component from the back.