




Fitting Instructions

MADE TO MEASURE
SHUTTERS


Fitting Instructions

Made To Measure Shutters


TOOLS REQUIRED



Tape Measure




Drill



Pozi 2 Screwdriver



9mm Drill Bit



Spirit Measure



Pencil



Step Ladders




Masonry Bit

You will also need wall plugs and packers/ shims.

FITTING COMPONENTS



25mm Screws




Screw Hole Covers

POSITIONING THE SHUTTER

Lift the shutter into the recess and position so it sits square and clear of any obstructions, such as window handles.


Use shims or packers to hold the shutter in position.



Fitting Instructions

Made To Measure Shutters

SIDE MOUNTING




Step 1

RECESS L FRAME

Drill 9mm holes for the screw caps through one skin on the shutter frame. The holes should be drilled at each hinge position on the sides, and where panels meet on the top and bottom.


More screws can be added if required.



Step 2

RECESS L FRAME


Drill a 3.5mm hole through the remaining frame until it marks the wall to indicate the fixing holes' position.



Step 3

RECESS Z FRAME

Remove the frame then drill holes for the wall plugs in the marked position. Insert the plugs and return the frame to the fitting position.



Step 4

RECESS Z FRAME

Line the holes in the frame up with the holes in the wall and screw into position (do not over tighten screws), checking the frame is square and level. Use packers or shims to fill any gaps.

MOUNT THE DOORS

If the shutters have been fitted with the doors removed, refit by holding the door in position and sliding the hinge pin through the hinges to lock them in place.

FINALISE THE FITTING

Now the shutter is secure in the recess, check that the doors open and close. If the frame is not square then further adjustment may be required to the frame.

The locking catch can be adjusted with a flat head screwdriver. With the flat head screwdriver, push the catch in and turn **CLOCKWISE** to ease the door closing and **ANTI-CLOCKWISE** to increase the locking force.

When happy with everything use the screw caps to fill the holes and fill the exterior gaps around the frame with caulk.



HALLIS HUDSON
Committed to excellence

Hallis Hudson, Unit C34, Red Scar Business Park, Longridge Road, Preston, Lancashire, PR2 5NN

Sales Tel: 01772 202 202 | Email: sales@hallishudson.com | www.halliswebshop.com

www.hallishudson.com

